

SuperPaint®**Exterior Latex Low Lustre**

A78-Q Series

**SHERWIN
WILLIAMS.****CHARACTERISTICS**

SuperPaint Exterior Latex, with resistance to early dirt pick up, provides outstanding performance on properly prepared aluminum and vinyl siding, wood, hardboard, masonry, cement, brick, block, stucco, and metal down to a surface and air temperature of 1.7°C (35°F).

VinylSafe™ paint colors allow you the freedom to choose from 100 color options, including a limited selection of darker colors formulated to resist warping or buckling when applied to a sound, stable vinyl substrate.

Color: Most Colors

Coverage: 350-400 sq. ft. per gallon
@ 4 mils wet, 1.4 mils dry

Drying Time, @ 50% RH:

@ 1.7°/7.2° C	@ 7.2° C +
@ 35-45° F	@ 45° F +

Touch:	2 Hours	2 Hours
Recoat:	24-48 Hours	4 Hours

Drying and recoat times are temperature, humidity, and film thickness dependent.

Finish: 10 units @ 60°

Tinting with CCE only:

Base:	oz. per gallon	Strength
Extra White	0-6	SherColor
Deep Base	4-12	SherColor
Ultra Deep Base	10-12	SherColor

Extra White A78WQ4151

(may vary by color)

V.O.C.(less exempt solvents):

Less than 50 grams per litre; 0.42 lbs. per gallon
As per 40 CFR 59.406

Volume Solids:	35 ±2%
Weight Solids:	59 ±2%
Weight per Gallon:	4.75 kg (10.49 lbs)
Flash Point:	N.A.
Vehicle Type:	100% Acrylic
Shelf Life:	36 months, unopened

Mildew Resistant

This coating contains agents which inhibit the growth of mildew on the surface of this coating film.

COMPLIANCE

As of 11/16/2023, Complies with :

OTC	Yes
OTC Phase II	Yes
S.C.A.Q.M.D.	Yes
CARB	Yes
CARBSCM 2007	Yes
CARB SCM 2020	Yes
Canada	Yes
LEED® v4 & v4.1 Emissions	N/A
LEED® v4 & v4.1 V.O.C.	Yes
EPD-NSF® Certified	N/A
MIR-Manufacturer Inventory	N/A
MPI®	No

APPLICATION

When the air temperature is at 1.7°C (35°F), substrates may be colder; prior to painting, check to be sure the air, surface, and material temperature are above 1.7°C (35°F) and at least 5° above the dew point. Avoid using if rain or snow is expected within 2-3 hours.

Do not apply at air or surface temperatures below 1.7°C (35°F) or when air or surface temperatures may drop below 1.7°C (35°F) within 48 hours. No reduction needed.

Brush:

Use a nylon-polyester brush.

Roller:

Use a high quality 3/8-3/4 inch nap synthetic roller cover.

For specific brushes and rollers, please refer to our Brush and Roller Guide on sherwin-williams.com

Spray - Airless:

Pressure	2000 p.s.i.
Tip	0.38-0.48mm (0.015-0.019 inch)

APPLICATION TIPS

Make sure product is completely agitated (mechanically or manually) before use.

Thoroughly follow the recommended surface preparations. Most coating failures are due to inadequate surface preparation or application. Thorough surface preparation will help provide long term protection.

SPECIFICATIONS

SuperPaint Exterior Latex can be self-priming when used directly over existing coatings, or bare drywall, plaster, and masonry (with a cured pH of less than 9). The first coat acts like a coat of primer and the second coat provides the final appearance and performance. Please note that some specific surfaces require specialized treatment.

Aluminum & Aluminum Siding¹, Galvanized Steel¹:

2 coats SuperPaint Exterior Latex

Concrete Block, CMU, Split face Block:

1 coat Loxon Acrylic Block Surfacers
2 coats SuperPaint Exterior Latex

Brick, Stucco, Cement, Concrete:

1 coat Loxon Concrete & Masonry Primer³
or
Loxon Conditioner²
2 coats SuperPaint Exterior Latex

Cement Composition Siding/Panels:

1 coat Loxon Concrete & Masonry Primer³
or
Loxon Conditioner²
2 coats SuperPaint Exterior Latex

Plywood:

1 coat Exterior Latex Primer
2 coats SuperPaint Exterior Latex

***Vinyl Siding:**

2 coats SuperPaint Exterior Latex

Wood (Cedar, Redwood)⁴:

1 coat Exterior Oil-Based Wood Primer²
2 coats SuperPaint Exterior Latex

¹ On large expanses of metal siding, the air, surface, and material temperatures must be 10°C (50°F) or higher.

² Not for use at temperatures under 10°C (50°F). See specific primer label for that product's application conditions.

³ Not for use at temperatures under 4.4°C (40°F). See specific primer label for that product's application conditions.

⁴ Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. For best results on these woods, use a coat of Exterior Oil-Based Wood Primer.

Other primers may be appropriate. Standard latex primers cannot be used below 50°F (10°C) or above 100°F (37.7°C). See specific primer label for that product's application limitations.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SuperPaint®

Exterior Latex Low Lustre

SURFACE PREPARATION

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer-sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Aluminum and Galvanized Steel:

Wash to remove any oil, grease, or other surface contamination. All corrosion must be removed with sandpaper, wire brush, or other abrading method.

Cement Composition Siding-Panels:

Remove all dirt, dust, grease, oil, loose particles, laitance, foreign material, and peeling or defective coatings. Allow the surface to dry thoroughly. If the surface is new, test it for pH, if the pH is higher than 9, prime with Loxon Concrete & Masonry Primer.

Caulking:

Gaps between windows, doors, trim, and other through-wall openings can be filled with the appropriate caulk after priming the surface.

Masonry, Concrete, Cement, Block:

All new surfaces must be cured according to the supplier's recommendations – usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer. Cracks, voids, and other holes should be repaired with an elastomeric patch or sealant. **Concrete masonry units (CMU)** - Surface should be thoroughly clean and dry. Air, material, and surface temperatures must be at least 50°F (10°C) before filling. Use Loxon Acrylic Block Surfer. The filler must be thoroughly dry before topcoating.

Stucco:

Remove any loose stucco, efflorescence, or laitance. Allow new stucco to cure at least 30 days before painting. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Repair cracks, voids, and other holes with an elastomeric patch or sealant.

SURFACE PREPARATION

Mildew:

Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts clean water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with clean water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach-water solution.

Previously Painted Surfaces:

If in sound condition, clean the surface of all foreign material. Smooth, hard, or glossy coatings and surfaces should be dulled by abrading the surface. Apply a test area, allowing paint to dry one week before testing adhesion. If adhesion is poor, additional abrasion of the surface and/or removal of the previous coating may be necessary. Retest surface for adhesion. If paint is peeling or badly weathered, clean surface to sound substrate and treat as a new surface as above. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Steel:

Rust and mill scale must be removed using sandpaper, wire brush, or other abrading method. Bare steel must be primed with a corrosion resistant primer such as All Surface Enamel Primer the same day as cleaned.

***Vinyl or other PVC Building Products:**

Clean the surface thoroughly by scrubbing with warm, soapy water. Rinse thoroughly, if needed prime with appropriate white primer. Do not paint vinyl with any color darker than the original color or having a Light Reflective Value (LRV) of less than 56 unless VinylSafe® Colors are used. If VinylSafe colors are not used the vinyl may warp. Follow all painting guidelines of the vinyl manufacturer when painting. Only paint properly installed vinyl siding. Deviating from the manufacturer's painting guidelines may cause the warranty to be voided.

Wood, Plywood, Composition Board:

Clean the surface thoroughly then sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. All new and patched areas must be primed. Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, it may show some staining. If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using.

CAUTIONS

For exterior use only.
Protect from freezing.
Non-Photochemically reactive.
Not for use on floors

Before using, carefully read **CAUTIONS** on label.

MAY IRRITATE EYES: Do not get in eyes. Keep out of reach of children. **FIRST AID TREATMENT:** Contains: Surfactants. If swallowed, call a Poison Control Centre or doctor immediately. Do not induce vomiting. If in eyes, rinse with water for 15 minutes.

HOTW	11/16/2023	A78WQ4151	01	32
HOTW	11/16/2023	A78WQ4153	01	37
HOTW	11/16/2023	A78TQ4154	01	43

FRC

CLEANUP INFORMATION

Clean spills, spatters, hands and tools immediately after use with soap and warm clean water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.