

ProMar®**Interior-Exterior Semi-Gloss Block Filler and Finish**

B25W00035

**SHERWIN
WILLIAMS®****CHARACTERISTICS**

ProMar Interior-Exterior Semi-Gloss Block Filler and Finish has excellent filling characteristics and is designed to provide a high build filling and finish system in one product.

Color: Off White

Coverage: **Smooth surfaces:**
75-125 sq.ft.per gallon

Rough surfaces:
60-100 sq.ft.per gallon

Drying and recoat times are temperature, humidity, and film thickness dependent

Drying Time, @ 77°F, 50% RH:

Touch: 2 hours

Recoat: 24 hour

Finish: 25-35 units@60°

Tinting with CCE:

Base	oz.per gallon	Strength
White	0-4	SherColor

White B25W00035

V.O.C. (less exempt solvents):

95 grams per litre; .79 lbs. per gallon
As per 40 CFR 59.406

Volume Solids: 38 ± 2%

Weight Solids: 49 ± 2%

Weight per Gallon: 10.21 lbs

Flash Point: N.A.

Vehicle Type: Vinyl Acrylic

Shelf Life: 36 months unopened

WVP Perms (US) 49.46 grains/(hr ft2 in Hg)

COMPLIANCE

As of 05/26/2020, Complies with:

OTC	Yes
OTC Phase II	Yes
SCAQMD	No
CARB	Yes
CARB SCM 2007	Yes
Canada	Yes
LEED® v4 & v4.1 Emissions	No
LEED® v4 & v4.1 V.O.C.	No
EPD-NSF® Certified	No
MIR-Manufacturer Inventory	No
MPI®	No

APPLICATION

Apply at temperatures above 50°F.

Do not reduce.

Brush:
Use a nylon/polyester brush.

Roller:
Use a 3/8-1^{1/2} inch nap synthetic cover.

For specific brushes and rollers, please refer to our Brush and Roller Guide on sherwin-williams.com

Spray—Airless:

Reduction as needed up to 1 pint per gallon

Remove all in-line and gun filters

Pressure 2000 p.s.i.

Tip .019-.028 inch

APPLICATION TIPS

Apply paint at the recommended spreading rate as indicated. Application of coating below minimum recommended spreading rate may adversely affect the coating systems performance.

ProMar Block Filler-Finish is ready-to-spray (airless) and does not require thinning. Mix material thoroughly to a uniform consistency with power agitation and apply by brush, roller, or spray. If applied by airless spray, follow by roller, being careful to force material into pores in order to reduce pinholes and produce a relatively smooth surface. Squeegee or trowel will provide the smoothest finish. Two coats properly applied may be required to provide the most uniform surface.

SPECIFICATIONS

Masonry, Concrete, Cement, Block

1 coat ProMar Interior-Exterior Semi-Gloss Block Filler and Finish

optional

2 coats ProMar Interior-Exterior Semi-Gloss Block Filler and Finish

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (**NIOSH** approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Masonry, Concrete, Cement, Block:

Remove all surface contamination, form release agents, moisture curing membranes, etc. by washing with an appropriate cleaner, rinse and allow to dry. Pressure wash the surface if needed. Remove existing peeled or checked paint to a sound surface. Concrete and mortar must be cured, generally 30 days, at 75°F before painting.

Complete removal of sealers, release compounds, and to provide a profile, tilt-up and poured-in-place concrete could require sandblasting or cleaning with commercial detergents. Do not apply to smooth, slick surfaces. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Masonry surfaces must be dry before priming. Moisture content must be 15% or lower, and the pH between 6 and 9. If the pH is greater than 9, use Loxon Block Surfer in place of ProMar Block Filler.

For repairing exterior cracks, bugholes, air pockets, and other voids use an elastomeric patch or seal.

SURFACE PREPARATION

Mildew:

Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.

CAUTIONS

Protect from freezing.

For interior and exterior use.

Do not apply to damp or wet surfaces.

Do not use below grade as a hydrostatic waterproofer or in immersion service.

Before using, carefully read CAUTIONS on label

Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (**NIOSH** approved) or leave the area. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. **FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.**

HOTW 05/26/2020 B25W00035 21 95

CLEANUP INFORMATION

Clean spills, spatters, hands and tools with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.