

Opulence®**Interior Latex Low Sheen Eg-Shel**

D19WQ8151 Extra White, D19WQ8153 Deep Base,
D19TQ8154 Ultradeep Base



**SHERWIN
WILLIAMS®**

CHARACTERISTICS

Opulence Interior Latex glides on buttery smooth and levels out... giving walls an elegant, silky rich look. The result is a difference you can definitely see and feel.

- Ultra-smooth, rich, silky finish.
- Silky, low-stipple appearance that looks good from all angles.
- Looks, feels and applies smooth and buttery.
- Outstanding coverage and hide.
- Paint and Primer in one.
- Scrubbable for easy cleaning and maintenance.
- Ideal for residential spaces.

Color: Many Colors

To optimize hide and color development, always use the recommended P-Shade primer

Coverage: 350 - 400 sq.ft. per gallon
@ 4 mils wet; 1.6 mils dry

Drying Time, @ 77°F, 50% RH:

Touch: 1 Hour
Recoat: 4 Hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: 11-17 units @ 85°

Tinting with CCE only:

Base:	oz.per gallon:	Strength:
Extra White	0-7	SherColor
Deep Base	4-12	SherColor
Ultradeep Base	10-12	SherColor

Extra White D19WQ8151
(may vary by color)

V.O.C. (less exempt solvents):

less than 50 grams per litre; 0.42 lbs. per gallon
As per 40 CFR 59.406

Volume Solids:	40 ± 2%
Weight Solids:	51 ± 2%
Weight per Gallon:	10.56 lbs
Flash Point:	N/A
Vehicle Type:	Vinyl Acrylic
Shelf Life:	36 months unopened

COMPLIANCE

As of 10/06/2020, Complies with:

OTC	Yes
OTC Phase II	Yes
SCAQMD	Yes
CARB	Yes
CARB SCM 2007	Yes
Canada	Yes
LEED® v4 & v4.1 Emissions	No
LEED® v4 & v4.1 V.O.C.	Yes
EPD-NSF® Certified	No
MIR-Manufacturer Inventory	No
MPI®	No

APPLICATION

Apply at temperatures above 50°F.
No reduction needed.

Brush:

Use a nylon-polyester brush.

Roller:

Use 3/8-3/4 inch nap synthetic cover.

For specific brushes and rollers, please refer to our Brush and Roller Guide on sherwin-williams.com

Spray—Airless

Pressure 2000 p.s.i.
Tip .017-.021 inch

APPLICATION TIPS

Make sure product is completely agitated (mechanically or manually) before use.

Priming and application of two coats at the recommended film thickness can help where hiding of a previous coating or application to new drywall is a factor.

SPECIFICATIONS

Drywall:

Self-prime using 2 coats of Opulence
or

1 coat Premium Wall and Wood Primer
2 coats Opulence Interior Latex

Masonry - Block: (can be filled to provide a smooth surface or primed if it is a high pH substrate)
1 coat Loxon Acrylic Block Surfer

or

1 coat Loxon Concrete & Masonry Primer
2 coats Opulence Interior Latex

Plaster:

1 coat Loxon Concrete & Masonry Primer
2 coats Opulence Interior Latex

Previously Painted:

1-2 coats Opulence Interior Latex

Wood:

1 coat Premium Wall and Wood Primer
2 coats Opulence Interior Latex

If the wood has bleeding (such as tannin or knot-holes), prime with Multi-Purpose Primer.

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer-sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Caulking:

Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.

Drywall:

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Cement, Block:

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete and Masonry Primer.

SURFACE PREPARATION**Mildew:**

Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach-water solution.

Plaster:

Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.

Wood:

Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.

CAUTIONS

For interior use only.
Protect from freezing.
Non-photochemically reactive.

Before using, carefully read **CAUTIONS on label**

MAY IRRITATE EYES. Do not get in eyes. Keep out of reach of children. **FIRST AID TREATMENT.** Contains: Surfactants. If swallowed, call a Poison Control Centre or doctor immediately. Do not induce vomiting. If in eyes, rinse with water for 15 minutes.

HOTW 10/06/2020 D19TQ8154 02 00

CLEANUP INFORMATION

Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.